




Used parts


(Note: Some parts may be different than images)

- | | | |
|--|--|--|
| 1. Gaslift
 | 2. Casters
 | 3. Armrests
 |
| 4. Synchro mechanism
 | 5. Seat
 | |
| 6. Base
 | 7. Backrest
 | 8. Headrest
 |
| 9. Screws
 | | |

Model M1 / armrests K13

A	M6x30	6 pcs	2 pcs armrests + 4 pcs mechanism
B	M8x14	3 pcs	Backrest
C	M6x35	4 pcs	Armrests
D	M5x20	2 pcs	Headrest


Model M1 / armrests 3B

A	M6x30	10pcs	6 pcs armrests + 4 pcs mechanism
B	M8x14	3 pcs	Backrest
D	M5x20	2 pcs	Headrest
	1 pcs	IMBUS	

Assembly instructions - model M1 with seat depth regulation


STEP 1

1. Insert armrests to the seat
2. Be aware of the correct position of the left and right armrests
3. Fasten the screws Ax2pcs + Cx4pcs for **armrest K13**, or Ax6pcs for **3B armrests**



STEP 2

1. Fasten mechanism to the seat
2. Tighten the screws A x 4pcs



STEP 3

1. Fasten backrest to the mechanism
2. Tighten the screws B x 3pcs



STEP 4

1. Insert 5pcs of casters into the base, then insert gaslift into the opening in the base
2. Insert the gaslift into the corresponding hole in the mechanism



STEP 5

1. Fasten headrest to the backrest
2. Tighten the screws D x 2pcs



User guide

Maintenance and attention

1. The chair can only be used by one person at a time.
 2. Do not use the chair as a stool or ladder.
 3. Do not use the chair unless all parts are properly assembled.
 4. Do not use the chair unless all screws are properly tightened.
 5. If the chair is damaged by external influences, do not use it without expert repair.
 6. This is a mechanical product subjects to user stress, it is necessary to check the chair regularly and possibly tighten the screws.
- For professional servis, please contact us by phone +420 463 034 155 or by mail export1@emagra.cz



Using instructions- model M1 with depth regulation



Height regulation of backrest UP-DOWN



Height regulation by gaslift



4D adjustable **3B armrests** with softened polyurethane foam on the touch part
Options of regulation:
height and width
forward / backward
rotatable left/right

Headrest adjustable in height and angle



Separately adjustable lumbar support – height 10 cm, width 2,5 cm

Handle for regulation of mechanics stiffness according to users weight